



SHOULDER BAGS



| Category | Name | CAMERA BODY | | | | | LENSES | | | | | | ACCESSORIES | | | |
|-----------|--------------|--------------|---------------|----------|------------|------------|--------|--------|---|--------|----|----------|-------------|-------|--------|--------|
| | | Compact DSLR | Standard DSLR | Pro DSLR | Pro + Grip | Mirrorless | 1 | 1 to 2 | 2 | 3 to 4 | 5+ | 70-200mm | 600mm | Flash | Laptop | Tablet |
| ZUMA | Zuma 3 | ✓ | | | | | | ✓ | | | | | | ✓ | | ✓ |
| | Zuma 4 | | ✓ | | | | | ✓ | | | | ✓ | | ✓ | | ✓ |
| | Zuma 5 | ✓ | | | | | | | ✓ | | | | | ✓ | ✓ | |
| | Zuma Compact | | | | | ✓ | | ✓ | | | | | | ✓ | | |
| ULTRA PRO | Ultra Pro 7 | | | ✓ | | | | | ✓ | | | ✓ | | ✓ | | |
| | Ultra Pro 11 | ✓ | ✓ | | | | | | ✓ | | | | | ✓ | | ✓ |
| | Ultra Pro 13 | ✓ | ✓ | | | | | | ✓ | | | ✓ | | ✓ | ✓ | |
| | Ultra Pro 17 | | ✓ | ✓ | | | | | ✓ | | | ✓ | | ✓ | ✓ | |
| PRO | Pro 8 | ✓ | ✓ | | | | | | ✓ | | | | | ✓ | | |
| | Pro 12 | | ✓ | ✓ | | | | | ✓ | | | | | ✓ | | |
| SYSTEM | System 2 | | ✓ | | | | | ✓ | | | | | | ✓ | | |
| | System 3 | | ✓ | | | | | | ✓ | | | | | ✓ | | |
| | System 6 | | | ✓ | | | | | ✓ | | | | | ✓ | | |
| ARIA | Aria 1 | | | | | ✓ | ✓ | | | | | | | ✓ | | |
| | Aria 2 | | | | | ✓ | | ✓ | | | | | | ✓ | | |
| | Aria 3 | ✓ | | | | | | ✓ | | | | | | ✓ | | |
| | Aria 6 | | ✓ | | | | | ✓ | | | | | | ✓ | | ✓ |



SHOULDER BAG



CAMERA BODY



LENSES



ACCESSORIES

| Category | Name | Compact DSLR | Standard DSLR | Pro DSLR | Pro + Grip | Mirrorless | 1 | 1 to 2 | 2 | 3 to 4 | 5+ | 70-200mm | 600mm | Flash | Laptop | Tablet |
|----------|------------------|--------------|---------------|----------|------------|------------|---|--------|---|--------|----|----------|-------|-------|--------|--------|
| RALLY | Rally Micro | | | | | ✓ | ✓ | | | | | | | ✓ | | |
| | Rally 2 | ✓ | | | | | | ✓ | | | | | | ✓ | | |
| | Rally 4 | | ✓ | | | | | ✓ | | | | | | ✓ | | |
| | Rally 5 | | ✓ | | | | | | ✓ | | | ✓ | | ✓ | | ✓ |
| | Rally 6 | | ✓ | | | | | | ✓ | | | ✓ | | ✓ | | |
| | Rally 7 | | ✓ | | | | | | | ✓ | | ✓ | | ✓ | ✓ | |
| EXPLORER | Explorer 1 | | ✓ | | | | | ✓ | | | | | | ✓ | | |
| | Explorer 2 | | ✓ | | | | | | ✓ | | | | | ✓ | | |
| | Explorer 100 | ✓ | | | | | | ✓ | | | | | | ✓ | | |
| | Explorer 200 | | ✓ | | | | | | ✓ | | | | | ✓ | | |
| | Explorer 400 | | | ✓ | | | | | ✓ | | | | | ✓ | | |
| AREO | Aero 36 | | | | | ✓ | | ✓ | | | | | | | | |
| | Aero 40 | ✓ | | | | | ✓ | | | | | | | ✓ | | |
| | Aero 45 | ✓ | | | | | | ✓ | | | | | | ✓ | | |
| | Aero 50 | | ✓ | | | | | | ✓ | | | | | ✓ | | |
| | Aero 60 | | | ✓ | | | | | ✓ | | | | | ✓ | | |
| JAZZ | Jazz 36 | | | | | ✓ | | ✓ | | | | | | ✓ | | |
| | Jazz 45 | ✓ | | | | | | ✓ | | | | | | ✓ | | |
| | Jazz Messenger 2 | ✓ | | | | | | ✓ | | | | | | ✓ | | |
| | Jazz Messenger 4 | | ✓ | | | | | ✓ | | | | | | ✓ | | |